

SUPREME 5-UNIT RADIO TESTER
 MODEL 444
 TUBE TESTING TABLE

<u>Tube Type</u>	<u>Fil-Htr Selector</u>	<u>Tube Test Selector</u>	<u>D.C.M.A. Range</u>	<u>D.C.M.A. Connections</u>	<u>Discard Minimum</u>
1A6	2.0	K	0- 5	2-2	0.9
2A3	2.5	A	0-125	2-2	7.8
2A5	2.5	D	0- 2.5	2-2	4.8
2A6	2.5	F	0- 5	2-2	0.48
2A7	2.5	C	0- 5	2-2	1.5
2B7	2.5	B	0- 25	2-2	1.5
2Y3	2.5	A	0-125	1-1	30.0
2Y3	2.5	A	0-125	2-2	30.0
2Y4	2.5	A	0-125	1-1	24.0
2Y4	2.5	A	0-125	2-2	24.0
5Z3	5.0	A	0-125	1-1	21.0
5Z3	5.0	A	1-125	2-2	21.0
6A4	6.3	E	0- 25	2-2	4.2
6A7	6.3	C	0- 5	2-2	1.5
6B7	6.3	B	0- 25	2-2	1.8
6C6	6.3	B	0- 5	2-2	1.5
6C7	6.3	F	0- 5	2-2	1.8
6D6	6.3	B	0- 25	2-2	2.2
6D7	6.3	B	0- 25	2-2	2.0
6E7	6.3	B	0- 25	2-2	2.7
6F7	6.3	D	0- 5	2-2	1.9
6Y5*	6.3	A	0-125	1-1	30.0
6Y5*	6.3	J	0-125	5-5	30.0
6Z4	6.3	A	0-125	1-1	26.0
6Z4	6.3	A	0-125	2-2	26.0
12Z3	12.0	J	0-125	2-2	3.0
25Z5	25.0	J	0-125	2-2	30.0

#2-444 Tube Testing Table.

<u>Tube Type</u>	<u>Fil-Htr Selector</u>	<u>Tube Test Selector</u>	<u>D.C.M.A. Range</u>	<u>D.C.M.A. Connections</u>	<u>Discard Minimum</u>
25Z5	25.0	J	0-125	5-5	30.0
00A	5.0	A	0- 5	2-2	1.3
01-A	5.0	A	0- 25	2-2	1.8
KR-1	6.3	J	0-125	2-2	30.0
1-V	6.3	J	0-125	2-2	30.0
1	6.3	J	0-125	2-2	27.0
G-2	2.5	H	0- 25	2-2	15.0
G-4	2.5	H	0- 5	2-2	2.7
10	7.5	A	0- 25	2-2	1.8
12A	5.0	A	0- 25	2-2	3.6
14	14.0	B	0- 5	2-2	1.1
15	2.0	C	0- 5	2-2	0.4
17	14.0	A	0- 25	2-2	2.4
18	14.0	D	0- 25	2-2	4.5
19	2.0	K	0- 5	2-2	1.1
20	3.3	A	0- 25	2-2	2.4
KR-20	2.5	A	0- 25	2-2	1.8
KR-22	6.3	A	0- 25	2-2	2.1
22	3.3	C	0- 5	2-2	0.42
24	2.5	B	0- 5	2-2	1.0
26	1.5	A	0- 25	2-2	1.5
27	2.5	A	0- 25	2-2	2.1
29	2.5	A	0- 5	2-2	7.2
30	2.0	A	0- 5	2-2	1.5
31	2.0	A	0- 25	2-2	3.0
32	2.0	C	0- 5	2-2	0.4
33	2.0	E	0- 25	2-2	3.9
34	2.0	C	0-25	2-2	6.6

#3-444 Tube Testing Table.

<u>Tube Type</u>	<u>Fil-Htr Selector</u>	<u>Tube Test Selector</u>	<u>D.C.M.A. Range</u>	<u>D.C.M.A. Connections</u>	<u>Discard Minimum</u>
35	2.5	B	0- 5	2-2	1.3
36	6.3	C	0- 5	2-2	1.0
37	6.3	A	0- 25	2-2	3.3
38	6.3	B	0- 25	2-2	4.2
39	6.3	B	0- 25	2-2	1.8
40	5.0	A	0- 5	2-2	0.6
41	6.3	D	0- 25	2-2	4.5
42	6.3	D	0- 25	2-2	3.6
43	25.0	D	0- 25	2-2	9.0
44	6.3	B	0- 25	2-2	1.8
45	2.5	A	0- 25	2-2	6.9
46	2.5	E	0- 25	2-2	4.8
47	2.5	E	0- 25	2-2	4.5
48	30.0	D	0-125	2-2	9.0
49	2.0	A	0- 5	2-2	0.6
50	7.5	A	0- 25	2-2	4.5
51	2.5	B	0- 5	2-2	1.0
52	6.3	A	0- 5	2-2	0.6
53	2.5	K	0- 5	2-2	1.1
55	2.5	F	0- 25	2-2	2.5
56	2.5	A	0- 25	2-2	6.5
57A	6.3	B	0- 25	2-2	2.1
57	2.5	B	0- 5	2-2	2.0
58A	6.3	B	0- 25	2-2	3.0
58	2.5	B	0- 25	2-2	2.7
59	2.5	I	0- 25	2-2	5.5
64A	6.3	B	0- 5	2-2	1.2
64	6.3	B	0- 5	2-2	0.6

#4- 444 Tube Testing Table.

<u>Tube Type</u>	<u>Fil-Htr Selector</u>	<u>Tube Test Selector</u>	<u>D.C.M.A. Range</u>	<u>D.C.M.A. Connections</u>	<u>Discard Minimum</u>
65A	6.3	B	0- 5	2-2	1.0
65	6.3	B	0- 5	2-2	1.5
67A	6.3	A	0- 25	2-2	3.5
67	6.3	A	0- 25	2-2	2.0
68A	6.3	B	0- 25	2-2	3.5
68	6.3	B	0- 25	2-2	4.0
69	6.3	A	0- 5	2-2	0.6
71A	3.0	A	0- 25	2-2	6.6
75	6.3	F	0- 5	2-2	0.5
77	6.3	B	0- 5	2-2	1.5
78	6.3	B	0- 25	2-2	3.0
79	6.3	A	0- 5	2-2	0.5
80	5.0	A	0-125	1-1	24.0
80	5.0	A	0-125	2-2	24.0
81	7.5	A	0-125	2-2	18.0
82	2.5	A	0-125	1-1	27.0
82	2.5	A	0-125	2-2	27.0
83	5.0	A	0-125	1-1	27.0
83	5.0	A	0-125	2-2	27.0
G-84	2.5	A	0-125	2-2	21.0
84	6.3	A	0-125	1-1	26.0
84	6.3	A	0-125	2-2	26.0
85	6.3	F	0- 25	2-2	2.5
89	6.3	B	0- 25	2-2	4.5
99	3.3	A	0- 5	2-2	0.6
401*	3.3	A	0- 25	2-2	1.5
482B	5.0	A	0- 25	2-2	3.5
483	5.0	A	0- 25	2-2	3.5

#5- 444 Tube Testing Table

<u>Tube Type</u>	<u>Fil-Htr Selector</u>	<u>Tube Test Selector</u>	<u>D.C.M.A. Range</u>	<u>D.C.M.A. Connections</u>	<u>Discard Minimum</u>
484	3.3	A	0- 25	2-2	1.8
485	3.3	A	0- 25	2-2	1.8
486	3.3	A	0- 5	2-2	0.6
AD	6.3	J	0-125	2-2	30.0
AF	2.5	A	0-125	1-1	27.0
AF	2.5	A	0-125	2-2	27.0
AG	5.0	A	0-125	1-1	27.0
AG	5.0	A	0-125	2-2	27.0
GA	5.0	E	0- 25	2-2	3.5
LA	6.3	E	0- 25	2-2	4.2
PZ	2.5	E	0- 25	2-2	4.2
PZH	2.5	I	0- 25	2-2	4.5
WUND-A	2.5	A	0- 25	2-2	1.5
WUND-A	6.3	A	0- 25	2-2	1.5

*When testing the type 6Y5, test the first plate by setting the "TUBE TEST SELECTOR" at position "A," and depressing the "RECTIFIER, 2ND PLATE" switch button; test the second plate by rotating the "TUBE TEST SELECTOR" to position "J," and again depress the "RECTIFIER, 2ND PLATE" switch button. When testing the type 401, connect the heater terminals on the side or top of the tube, with suitable test lead conductors, to the filament pin jacks numbered "3" and "4."

SUPREME INSTRUMENTS CORPORATION

GREENWOOD, MISSISSIPPI

U. S. A.



Publication Digitized and Provided By

www.StevenJohnson.com

Vintage Schematics, and Publications

Steve's Antique Technology